Power Loop Instructions

Baniss

*Note: When not using pedal manual loop switch on front of amp must be in UP position. DOWN position when using Pedal.

Power Outlet ⊕ ⊙ 2.1mm Negative tip. Pedal power outlet 9v @ 1A. Capable of powering an entire pedal board.

> Loop Function Indicator LED Illuminates when effects loop is engaged.

Footswitch Cable Jack TRS (Stereo) 1/4" to 1/4" cable provides a path for effects loop in/out control on the Dirty Red. Also carries pedal power from amp to pedal.

Footswitch Turns effects loop on/off.

